

Using and Defining Superelevation

This course is for the 2021 Release 1 version of:

OpenRoads Designer CONNECT Edition

OpenRail Designer CONNECT Edition

About this Practice Workbook...

- This workbook is designed for use in Live instructor-led training and for OnDemand self study. OnDemand videos for this course are available on the [LEARNserver](#) and through [CONNECT Advisor](#).
- This PDF file includes bookmarks providing an overview of the document. Click on a bookmark to quickly jump to any section in the file.
- Both Imperial and Metric files are included in the dataset. Throughout this practice workbook Imperial values are specified first and the metric values second with the metric values enclosed in square brackets. For example: *12.0' [3.4m]*.
- This course workbook uses the [Training and Examples](#) WorkSpace and the [Training-Imperial](#) or [Training-Metric](#) WorkSet delivered with the software.
- The terms “Left-click”, “Click”, “Select” and “Data” are used interchangeably to represent pressing the left mouse button. The terms “Right-click” and “Reset” are also used interchangeably to represent pressing the right mouse button. If your mouse buttons are assigned differently, such as for left-handed use, you will need to adjust accordingly.

Have a Question? Need Help?

If you have questions while taking this course, search in [CONNECT Advisor](#) for related courses and topics. You can also submit questions to the Civil Design Forum on Bentley Communities where peers and Bentley subject matter experts are available to help.

Edition: **05-01**

Course Level: **Intermediate**



Course Overview

The intent of this course is to learn how to create, edit and review superelevation information using the tools provided in OpenRoads Designer. You will learn about the Superelevation XML preference file that controls how superelevation is calculated. You will learn how to create superelevation sections, lanes and transitions and how to apply the superelevation transitions to your corridor. You will also learn how to review and edit superelevation data.

Skills Taught

- Superelevation XML Preferences File - Create/Edit Super XML
- Creating Superelevation Sections and Lanes
- Calculating Superelevation
- Superelevation Reports
- Importing Superelevation Data
- Modifying Superelevation
- Assigning Superelevation to Corridor and Review Cross Sections

Course Prerequisites

Prior to beginning this course it is recommended that you have completed the following courses:

- QuickStart for Geometry - Road
- QuickStart for Corridor Modeling - Road

Superelevation Overview and Terminology

Superelevation is the rotation of the pavement on the approach to and through a horizontal curve. Superelevation calculations are used to determine how the roadway pavement will transition from normal cross slope to a fully superelevated section and back again.

The concept of superelevation is simple but many agencies and countries apply superelevation to their projects differently. Before getting started with superelevation a few basic terms need reviewing:

Maximum Superelevation Rate (e_{\max}): Based on local conditions, this is the maximum cross slope allowed for any curve for a given design speed.

Superelevation Rate (e): Indicates the design cross slope used for a given design speed, horizontal curve radius and e_{\max} .

Table 3-8. Minimum Radii for Design Superelevation Rates, Design Speeds, and $e_{\max} = 4\%$

Metric	Metric								
	$V_d = 20$ km/h	$V_d = 30$ km/h	$V_d = 40$ km/h	$V_d = 50$ km/h	$V_d = 60$ km/h	$V_d = 70$ km/h	$V_d = 80$ km/h	$V_d = 90$ km/h	$V_d = 100$ km/h
e (%)	R (m)	R (m)	R (m)	R (m)	R (m)	R (m)	R (m)	R (m)	R (m)
NC	163	371	679	951	1310	1740	2170	2640	3250
RC	102	237	441	632	877	1180	1490	1830	2260
2.2	75	187	363	534	749	1020	1290	1590	1980
2.4	51	132	273	435	626	865	1110	1390	1730
2.6	38	99	209	345	508	720	944	1200	1510
2.8	30	79	167	283	422	605	802	1030	1320
3.0	24	64	137	236	356	516	690	893	1150
3.2	20	54	114	199	303	443	597	779	1010
3.4	17	45	96	170	260	382	518	680	879
3.6	14	38	81	144	222	329	448	591	767
3.8	12	31	67	121	187	278	381	505	658
4.0	8	22	47	86	135	203	280	375	492

Superelevation Rate Example

Pivot Point (or Point of Rotation): Determines the point on the cross section that the superelevated lanes rotate about.

Relative Gradient (G): The slope of the edge of pavement relative to the axis of rotation. Used to determine the superelevation runoff length.

Runoff Length (L_r): Length required to transition a 0% cross slope to full superelevation.

Tangent Runout Length (L_t): Length required to transition from normal crown to 0% cross slope.


Location of Superelevation: Generally a certain percentage of the Runoff Length (L_r) or Total Length ($L_r + L_t$) is placed on the horizontal curve.

Adjustment Factors for Number of Lanes rotated (b_w): Used to reduce the length of transition when multiple lanes are rotated to reduce excessively long transition lengths.

Superelevation XML Preferences (or Rules File): OpenRoads Designer uses an XML-formatted rules file to calculate various aspects of superelevation. The XML preferences file can calculate superelevation rates for each curve of an alignment and the transition lengths needed to rotate the road from normal crown cross slope(s) to full superelevation cross slope.

Superelevation Section: Defines the limits of superelevation for a curve or set of curves. The section(s) are created based on the minimum tangent between curves.

Superelevation Lanes: Defines the number of pavement lanes and the width of the pavement lanes that superelevation calculations will be applied to.



Superelevation Workflow

The typical steps for creating superelevation is as follows:

1. Create a 2D dgn file where the superelevation data will be stored

TIP: A best practice is to create superelevation data in its own 2D dgn file. It can also be created in the geometry or corridor dgn files as needed.

2. Attach horizontal geometry reference file (Horizontal geometry is required to create superelevation).
3. Create the superelevation section(s).
4. Define the superelevation lanes.
5. Calculate superelevation transitions and cross slopes.
6. Review and edit as needed.
7. Assign superelevation to a corridor.

Exercise 1: Review and Edit Superelevation XML Preferences

In this exercise, we will review and edit the superelevation XML preferences.

Skills Taught

- Review the Superelevation Rules File
- Edit Superelevation Preferences


Start the Software

In this section, you will start the software, set the proper workspace and open and review the S.R. 97 Superelevation file.

1. Start the software.
2. Set the WorkSpace and WorkSet
 - a. Select **Training and Examples** from the *WorkSpace* menu.
 - b. Select **Training-Imperial** [*Training-Metric*] from the *WorkSet* menu.
3. Open **Super-SR97.dgn** [*Metric - Super-SR97.dgn*]



- a. Select **Browse**
 - b. Browse to *c:\Bentley Training\Using and Defining Superelevation* or other folder where you unzipped the dataset files.
 - c. Select the file named **Super-SR97.dgn** [*Metric - Super-SR97.dgn*]
 - d. Left click **Open**
4. Review the file and note the geometry has already been attached as a reference file. Prior to creating superelevation the geometry needs to be attached as a reference file or exist in the active design file.



Superelevation XML Preferences (or Rules File)

Prior to creating Superelevation it's important to understand how OpenRoads Designer will be calculating Superelevation. There are many tables, rates and equations that can be adjusted to handle almost any superelevation design. All of the tables, rates and equations required to calculate superelevation are contained in a Superelevation XML preference file or Rules File. Two superelevation XML preference files are delivered with the product and are based on the AASHTO 2011 and 2018 design standards. One file is set up for english values and one is set up for metric values.

The superelevation XML preference files delivered with the software can be found here:

C:\ProgramData\Bentley\Open RoadsDesigner CE\Configuration\Organization-Civil_Civil Default Standards - Imperial\Superelevation\AASHTO2018_Imperial.xml

C:\ProgramData\Bentley\Open RoadsDesigner CE\Configuration\Organization-Civil_Civil Default Standards - Metric\Superelevation\AASHTO_2018_Metric.xml

By default the software is set up to calculate superelevation based on AASHTO 2018. The superelevation XML file is fully customizable, if you use a different method to calculate superelevation all you have to do is customize the XML preference file to meet your needs. OpenRoads Designer provides a create/edit tool that allows you to create and edit the superelevation XML preferences easily.

The screenshot displays the 'Create / Edit Superelevation XML (Untitled.xml)' interface. The left pane shows XML code defining variables and a table for speed-based superelevation values.

```
<RateEquation name="2011 AASHTO Method 5 - 8% max rate" equation="eRate">
  <Variable name="eRate" description="Calculated cross slope value" equation="if(R <lt; MinRadius ? MaxERate : if
  <Variable name="MaxERate" equation="0.08"/>
  <Variable name="R" equation="ABS(Radius)" description="Absolute radius"/>
  <Variable name="MinRadius" description="Minimum radius" equation="Speed*Speed/(15*(MaxERate+frictionFactor))"/>
  <Variable name="lowSpeed" equation="20.0"/>
  <Variable name="midSpeed" equation="50.0"/>
  <Variable name="highSpeed" equation="80.0"/>
  <Variable name="s1" equation="(HPI * rPI) / 5729.58"/>
  <Variable name="s2" equation="(frictionFactor - hPI) / (5729.58*((1/MinRadius) - (1/rPI)))"/>
  <Variable name="rPI" equation="(runningSpeed * runningSpeed) / (0.15 * (100 * MaxERate))"/>
  <Variable name="hPI" equation="((MaxERate * Speed * Speed) / (runningSpeed * runningSpeed)) - MaxERate"/>
  <Variable name="MO" equation="(5729.58/rPI) * ((1/MinRadius) - (1/rPI)) * ((s2 - s1)/2) * MinRadius"/>
  <Variable name="EPD" equation="Speed*Speed/(15*R)"/>
  <Variable name="F" equation="if(1/R <lt;= 1/rPI) ? (MO * ((rPI/R)^2) + ((5729.58*s1) / R)) : (MO * (((1/MinRadi
  <Variable name="NCRadius" description="normal crown radius base on design speed">
    <Table inputVariableName="Speed" interpolationType="useLowerBound">
      <TableEntry inputValue="15" outputValue="796"/>
      <TableEntry inputValue="20" outputValue="1410"/>
      <TableEntry inputValue="25" outputValue="2050"/>
      <TableEntry inputValue="30" outputValue="2830"/>
      <TableEntry inputValue="35" outputValue="3730"/>
      <TableEntry inputValue="40" outputValue="4770"/>
      <TableEntry inputValue="45" outputValue="5930"/>
      <TableEntry inputValue="50" outputValue="7220"/>
      <TableEntry inputValue="55" outputValue="8650"/>
      <TableEntry inputValue="60" outputValue="10300"/>
      <TableEntry inputValue="65" outputValue="12600"/>
      <TableEntry inputValue="70" outputValue="14100"/>
      <TableEntry inputValue="75" outputValue="15700"/>
      <TableEntry inputValue="80" outputValue="17400"/>
    </Table>
  </Variable>
</RateEquation>
```

The right pane shows configuration options:

- Units: Length: **Meters**, Station Rounding: **1**
- Cross Slope Rounding(%): **0.01**
- Calculate Superelevation Default Settings (optional):
 - e Max Method: **AASHTO Method 5**
 - Runoff Length Method: **AASHTO**
 - Pivot Method: **Crown**
 - Design Speed: **15**

Review and Edit Superelevation XML Preferences


In this section you will learn how to review and edit the superelevation XML preference file.

1. Review and Edit the *AASHTO_2011_Imperial.xml* superelevation preference file.



- a. Select **Corridors > Superelevation > Calculate > Edit Superelevation Rule File**


The Create/Edit Superelevation XML dialog will appear. This dialog is used to review and adjust the equations, variables and tables that are stored in the superelevation XML preference file.



2. Open the **AASHTO_2011_Imperial.xml** [*AASHTO_2011_metric.xml*] file.




- a. From the *Create/Edit Superelevation* dialog select **Open**
- b. Browse to *c:\Bentley Training\Using and Defining Superelevation*
- c. Select the **AASHTO_2011_imperial.xml** [*AASHTO_2011_metric.xml*] file
- d. Select **Open**, to load the file into the *Create/Edit Superelevation* dialog




On the left side of the dialog you will see a list of categories that you can review and make adjustment to superelevation data.

- *General* - Used to set the units, rounding and the default values for superelevation calculations
- *Equations* - Used to create or edit Rate and Transitions equations
- *Runout and Transition Options* - Allows the user to set the Runout Options and Transitions Options
- *Curve Overlap Adjustments* - Options to adjust Curve types
- *Custom Key Stations* - Used to create additional superelevation station
- *Run Time Variables* - Allows the you to define variables that will prompt the user to enter values before calculating superelevation


3. Change the Station Rounding value to round superelevation transitions to the nearest 5 foot station [1.0 meter]
 - a. From the *Create/Edit Superelevation XML* dialog, select the *General* category
 - b. In the *Station Rounding* field, enter a value of 5 [1]



4. Change the transition type to linear and percent of superelevation runoff on tangent to 0.67 (this represents 2/3 or 67%).
 - a. From the *Create/Edit Superelevation XML* dialog, select *Runout and Transition Options*.
 - b. Using the drop down list set the *Transition Type* to *Linear*.



c. In the *Percent on Tangent* field, enter a value of **0.67** (percentage values must be entered in decimal form).



d. Go to **File > Save** to save the Superlevation Rule File.

e. Close the *Create/Edit Superlevation XML* dialog.


f. Select **Yes** when prompted to save before closing.

Exercise 2: Create Superelevation Section and Lanes

In this exercise, you will learn how to create superelevation sections and lanes for a multi-lane divided highway.


Skills Taught

- Create Superelevation Section
- Create Superelevation Lanes By Road Template




Superelevation Section and Lanes

Superelevation Section defines the limits of superelevation for a curve or set of curves along your alignment. Single or multiple superelevation sections can be created. The number of sections that get created is based on the minimum tangent length between curves. If you are using one design speed, a consistent lane configuration and the same superelevation point of rotation then one superelevation section will suffice in most cases. Also, if importing superelevation or creating superelevation transitions manually one section can be used for an entire alignment since rule based superelevation calculations do not apply to manually created superelevation transitions.



Multiple superelevation sections can be used when multiple design speeds are required or lane configuration and point of rotation varies along the alignment. *The advantage of multiple superelevation sections for each curve versus one large section is the ability to reprocess rules for a single curve set or more.*

Superelevation Lanes define the number of pavement lanes and the width of the pavement lanes that superelevation calculations will be applied to. Lanes are defined by offsets from the horizontal alignment and drawn graphically into the design file. The offsets and lane widths can be input manually via the on screen prompts or by selecting a template from the template library. Once the superelevation lanes are created superelevation transitions can then be calculated and assigned to each set of lanes.



Create Superelevation Section and Lanes

In this section, you will create the superelevation section and lanes along the SR97-Extension alignment. By utilizing a template from the template library the number of lanes and lane widths will be created automatically since they are already defined in the template. The template we will be using is a 4 lane divided highway template with the profile grade line located at the inside edge of pavement.

1. Create the superelevation section for SR97 Extension.



a. Select **Corridors > Superelevation > Create > Create Superelevation Sections**


b. Set the *Feature Definition* to **Superelevation** and key-in **SE** in the *Name* field.

c. Follow the heads up prompts (key in the values listed below and **Left click** to accept and move to the next prompt):


- *Name:* **SR97**
- *Locate Corridor or Alignment:* Select the **Route97-Extension** horizontal alignment.
- *Start Station:* **538+00 [16+400]**
- *End Station:* Press **ALT** to Lock To End
- *Minimum Tangent Length:* **10000 [3000]**
- *Lane Creation Method:* **Template**
- *Select Template:* Press **ALT** Down arrow to open the template library.
- Expand the template library folders to **Templates > Rural > Asphalt Pavt w/Asphalt Shoulders > Divided > 4 Lanes Inside Edge PGL**
- Select the **4 Lanes Inside Edge PGL** template

d. Review the template and note the inside edge of pavement points will be used as the location of the profile grade line and also serve as the point of rotation for superelevation.

e. Click **OK** to close the *Pick Template* window and then **Left Click** to complete.



The superelevation lanes will now be created in the design file. Using a template from the template library to create the lanes is a more efficient workflow than creating the lanes manually because the number of lanes and lane widths are already defined in the template.



Notes:

The *Minimum Tangent Length* value is the determining factor on how superelevation sections are defined between curves along an alignment. Section(s) are created based on “Minimum Tangent Length Between Curves”.

- Specified value < actual tangent length, Section is broken between curves.
- Specified value > actual tangent length, Section will include both curves.

If you want a single Superelevation section for entire alignment, use a value larger than the largest tangents (i.e. 10,000).

If you want each curve to have its own section (i.e. to deal with different design speeds), use a value smaller than the smallest tangent (i.e. 0).

Now that you have learned how to create the superelevation section and lanes, the next step will be to calculate the superelevation transitions and assign them to the superelevation lanes.

Exercise 3: Calculate Superelevation (Rules-Based)

In this exercise, you will learn how to calculate the superelevation transitions for a multi-lane divided highway using the superelevation XML preferences file and how to review superelevation data by creating a superelevation report.

Skills Taught

- Calculate Superelevation Transitions Using XML Preferences File
- Review Superelevation Reports

Superelevation Calculations

Superelevation can be calculated in 2 ways:

Rules-Based Calculations

- Superelevation XML Preferences File (or Rules File) - Superelevation is calculated using a rules based xml file that contains all the tables, equations and variables of a particular design standard. Since this option is rules based any changes made to the horizontal geometry will update superelevation calculations accordingly.

Manual Based Calculations (defined by the user)

- Import From Spreadsheet - Superelevation station and cross slope information can be imported from a comma separated values .csv file.
- Insert Stations and Cross Slopes - Superelevation stations and cross slopes can be manually inserted onto the superelevation lanes.
- Graphical Superelevation Diagram - Superelevation station and cross slope information can be created by graphically drawing a superelevation diagram in the superelevation model view.

Note: Since the above methods are manual, superelevation calculations will not automatically update when changes are made to the horizontal geometry.

Calculate Superelevation

In this section you learn how to calculate the superelevation transitions for a multi-lane divided highway using the AASHTO_2011 XML preferences file. Recall, the XML preferences file contains all of the superelevation rates, equations and tables necessary to calculate superelevation transitions. We will be using a design speed of **70 mph [110 kph]**, $e_{\max} = 6\%$ and the pavement will be rotated about the inside edge.

1. Calculate superelevation using the AASHTO_2011 XML preferences file.



a. Select **Corridors > Superelevation > Calculate > Calculate Superelevation**

b. Following the heads up prompts (after each prompt, **Left click** to accept values and move to next prompt):


- *Locate First Superelevation Section:* Select the superelevation section.
- *Locate Next Superelevation Section - Reset To Complete:* **Right click or Reset**
- *Select Rules File - Alt Down To Select File:* Press **<ALT><Down Arrow>** and select **c:\Bentley Training\Using and Defining Superelevation\AASHTO_2011_Imperial.xml [AASHTO_2011_Metric.xml]**
- *e Selection:* **6%**
- *L Selection:* **Speed Table**
- *Design Speed:* **70 [110 kph]**
- *Pivot Method:* **Divided Inside** (use the **<ALT> <Down Arrow>** to select from list)
- *Open Editor:* **No**

c. Right click or reset to complete.

In this example, the design superelevation rate e_d and superelevation runoff length L_r are calculated using the values in the AASHTO 2011 Superelevation Tables for a design speed of 70 mph **[110 kph]** and e_{\max} of 6%.

Upon completion, superelevation transitions will be created and assigned to each lane. The color filled superelevation lanes are drawn with rainbow-like colors that indicate various cross slopes. The coloring is hard-coded based on the cross slope:

- Slope < -10% =blue
- -10% <= Slope <= -0.5% = Calculated color between green and blue
- -0.5% < Slope < 0.5% = white
- 0.5% <= Slope <= 10% = Calculated color between red and yellow
- Slope > 10% = dark red



Note: The View Attribute for Fill must be toggled **On** to view the color coded fill. The superelevation lane fill settings can also be adjusted under **File > Settings > User > Preferences > View Options - Civil, Superelevation Settings** listing the following options:


- Color Shaded Fill - Color fills superelevations lanes AFTER calculations are complete
- Boundaries Only - In this option, only the outside boundary of each lane is displayed and can be selected.
- None - No superelevation lanes/edit handlers are displayed, however, they are still in the file. To display them, set to one of the other two options.

2. Review the superelevation transitions assigned to the lanes.

a. **Select** any superelevation lane. Notice graphic handlers appear with the station and cross slope information.

To edit the station or cross slope, simply click on the station text or cross slope text and enter a new value in the edit field. Stationing can also be changed dynamically by selecting the wedge shape and dragging it to the desired station.

The wedge shapes indicate the direction of the cross slope. A double wedge indicates 0% cross slope.



Create Superelevation Report and Review Transitions

In this section, you will learn to create the superelevation report and review the superelevation transitions.

1. Create Superelevation Report.



- a. From the ribbon menu select **Corridors > Superelevation > Superelevation Report**
- b. Select the superelevation section and **Right click** to accept it.

Superelevation Data Report
Report Created: Thursday, February 6, 2020
Time: 11:39:13 AM

Note: All units in this report are in feet unless specified otherwise.

File Name:
Input Grid Factor:

Section Name: SR97-1
Base Horizontal Name: Route97-Extension
Standards Filename: C:\Bentley Training\Using and Defining Superelevation\VAASHTO_2018_imperial.xml
Design Speed: 70
Pivot Method: Divided Inside
E Selection: 6%
L Selection: Speed Table


Superelevation: CL_L - EOP_L

Station	Cross Slope	Point Type	Transition Type
538+00.000	-2.000%	Normal Crown	
568+14.667	-2.000%	Normal Crown	Linear
569+08.000	0.000%	Level Crown	Linear
570+01.333	2.000%	Reverse Crown	Linear
571+60.000	5.400%	Full Super	Linear
577+05.000	5.400%	Full Super	Linear
578+63.667	2.000%	Reverse Crown	Linear
579+57.000	0.000%	Level Crown	Linear
580+50.333	-2.000%	Normal Crown	Linear
621+36.333	-2.000%	Normal Crown	Linear
622+95.000	-5.400%	Full Super	Linear
624+95.000	-5.400%	Full Super	Linear
626+53.667	-2.000%	Normal Crown	Linear
663+10.000	-2.000%	Full Super	Linear
694+95.000	-2.000%	Full Super	Linear

- 2. Review the superelevation information in the report. If you need to adjust the Station and Cross Slope format, go to **Tools > Format Options**.

3. Change the report type to review the superelevation calculations.
 - a. Select the **SuperelevationCalculation.xml** from the left portion of the *Bentley Civil Report Browser* dialog.

The report will change and display the superelevation calculation report. This report is used to review how the superelevations transitions were calculated and should be used to verify the results.



Superelevation Calculation Report

Report Created: Thursday, February 6, 2020
Time: 11:40:52 AM

Note: All units in this report are in feet unless specified otherwise.

File Name:
Input Grid Factor:

Section Name: SR97-1
Base Horizontal Name: Route97-Extension
Standards Filename: C:\Bentley Training\Using and Defining Superelevation\VAASHTO_2018_imperial.xml
Design Speed: 70
Pivot Method: Divided Inside
E Selection: 6%
L Selection: Speed Table
Calculation Units: US survey foot
Start Station: 538+00.000 **End Station:** 816+11.919

Lane Set: 1
Left Offset: -49.00
Right Offset: -25.00
Curve Set: 1 **Outside Lane:** CL_L - EOP_L

Global Variables:

NRotatedLanes	2.000
PivotType	5 (Divided Inside)
WidthLane	12.000
InitialCrossSlope	-0.020
UseSpiralLength	false
PercentOnTangent	0.670
LengthsAreTotalTransition	false
UseRunoutLength	false
Radius	3053.000
Speed	70.000

Maximum cross slope calculation

Max E Value: 5.400%
Result from: From Non-interpolated Table 6%

Transition length calculation

Transition Length: 252.000

Exercise 4: Import Superelevation (Manual and Non-rules Based)

In this exercise, you will learn how to import superelevation data using a .csv file (comma separated values). CSV files are typically created by exporting Excel spreadsheets. Many designers use an Excel spreadsheet for superelevation calculations in lieu of using OpenRoads Designer for superelevation calculations.

Skills Taught

- Format the .csv File
- Import .csv File
- Review Superelevation Reports

Import Superelevation from .csv file Workflow

Below are the general steps a user would take to import superelevation data from a.csv file.

1. Create the Superelevation Section(s) without using the XML Rules file.
2. Create the Superelevation Lanes.
3. Create the .csv, based on required file format.
4. Select Import Superelevation tool to import the .csv file.

CSV File Format

When importing superelevation data from a CSV file there is a specific format you must follow in order for OpenRoads Designer to be able to read the superelevation data properly. The format of the CSV file should be as follows:

SuperelevationName,Station,CrossSlope,PivotAbout,PointType,TransitionType,NonLinearCurveLength

The order is important, but you do not need every option.

For example, if all fields are used, one sample line is:

CL_RT1,2+50.000,-0.02,RS,NCIN,L,0

If only the required fields are used, one sample line is:

LT-1,2+50.000,-0.02,LS

List separators are needed to maintain the order of the options. One sample line is:

CL_RT1,2+50.000,-0.02,RS, ,PC,50

Format Definitions:

- *Superelevation Name* - Links the data to an existing superelevation lane, therefore, the name in the CSV file must match the lane names created prior to importation.
- *Station* - Units should match design file. Station equations are supported based on the section's reference alignment and the Design File Settings > Civil Formatting > Station Settings > Equation setting.
- *Cross Slope* - Formatted as a double value: ± 0.0 (i.e. -2% == -0.02)
- *Pivot About* - Enumerated list: {LS,RS} which refers to which edge to pivot about. Generally, if you are rotating about the center line, the right lane would pivot about the left edge (LS) while the left lane would pivot about the right edge (RS).

LS = left side RS = right side **Note:** The terminology is confusing here, where it refers to side rather than edge.

- *Point Type* - Enumerated list: {NC,NCIN,NCOUT,LC,LCIN,LCOUT,RC,RCIN,RCOUT,FS,FSIN,FSOUT,U}

NC = Normal Crown, LC = Level Crown, RC = Reverse Crown, FS = Full Super, U = Undefined

- *Transition Type* - Enumerated list: {L,PC,PRC,BRC,CRC,SRC}

L = Linear, PC = Parabolic Curve, PRC = Parabolic Reverse Curve, BRC = Biquadratic Reverse Curve, CRC = Cubic Reverse Curve, SRC = Symmetrical Reverse Curve

- *Non-Linear Curve Length* - Default Value = 0.0

Only used for transition type: parabolic curve or symmetrical reverse curve.

Review and Import Superelevation CSV File

In this section, we are going to review a previously created superelevation .csv file and then import the superelevation transitions from the .csv file.



1. Open the **Super-LondonRd.dgn** [*Metric - Super-LondonRd.dgn*].

Notice the superelevation section and lanes have already been created but superelevation transitions have not been applied to the lanes. This is by design, since our goal is to manually assign cross slopes to the lanes by importing superelevation data from a .csv file.

2. Review the superelevation section properties.

- a. Hover your cursor over the superelevation section shape until the context sensitive menu appears.



- b. **Select** the superelevation properties tool.

- c. **Review** the superelevation properties.

Feature Definition	Superelevation
Feature Name	LondonRd-1

Name	LondonRd-1
Horizontal Name	LondonRd

Start Station	50+00.0000
End Station	98+55.1889

Note that the superelevation section stores the limits and name of the superelevation section. Also, note that the superelevation xml rules and the design criteria are NOT assigned to this superelevation section. Since we are going to import superelevation data from an external file we do not need to use the xml rules file in this case. Superelevation transitions will be applied to the lanes based on the information in the .csv file.

Be aware that superelevation transitions will not update when changes are made to the horizontal geometry when using this method.

3. Review the superelevation .csv file.
 - a. Open the [SuperCalcs-LondonRd.csv](#) [*Metric - Supercalcs-LondonRd.csv*] file using Excel or any Windows Text Editor.
 - b. Review the stations and cross slopes and the format of the file.

SB	50+00.00	-0.02	RS	NC	L	0
SB	57+15.00	-0.02	RS	NC	L	0
SB	57+66.25	0	RS	U	L	0
SB	58+17.50	0.02	RS	RC	L	0
SB	59+20.00	0.06	RS	FS	L	0
SB	61+15.00	0.06	RS	FS	L	0
SB	62+20.00	0.02	RS	RC	L	0

c. Close the .csv file.

4. Import the [SuperCalcs-LondonRd.csv](#) [*Metric - Supercalcs-LondonRd.csv*] and assign the superelevation transitions to the lanes.




a. Select **Corridors > Superelevation > Calculate > Import Superelevation**

b. Following the heads up prompts (after each prompt, **Left click** to accept values and move to next prompt):

- *Locate Superelevation Section:* Select the superelevation section for London Rd.
- *Select Import File Name- Alt Down To Select File:* Press <ALT><Down Arrow> and select **C:\Bentley Training\Using and Defining Superelevation\SuperCalcs-LondonRd.csv** [*Metric - SuperCalcs-LondonRd.csv*].

c. When the *Import Superelevation* window appears, click **OK**.

Upon completion, the superelevation will change color indicating that the superelevation transitions have been imported.



5. Use the **Superelevation Report** tool to review the superelevation transitions.



a. From the ribbon menu select **Corridors > Superelevation > Superelevation Report**

b. Select the superelevation section.

c. Review the **Superelevation Data Report**

Bentley Civil Report Browser - C:\Users\scott.urbas\AppData\Local\Temp\RPT00djhdy.xml

File Tools Help

C:\Program Files\Bentley\OpenRoads Designer\CONNECT

Superelevation Data Report

Report Created: Thursday, February 6, 2020
Time: 11:52:08 AM

File Name:
Input Grid Factor:

Note: All units in this report are in feet unless specified otherwise.

Section Name: LondonRd-1
Base Horizontal Name: LondonRd

Superelevation: SB

Station	Cross Slope	Point Type	Transition Type
50+00.000	-2.000%	Normal Crown	
57+15.000	-2.000%	Normal Crown	Linear
57+66.250	0.000%	Undefined	Linear
58+17.500	2.000%	Reverse Crown	Linear
59+20.000	6.000%	Full Super	Linear
61+15.000	6.000%	Full Super	Linear
62+20.000	2.000%	Reverse Crown	Linear
62+72.500	0.000%	Undefined	Linear
63+25.000	-2.000%	Normal Crown	Linear
84+30.000	-2.000%	Normal Crown	Linear
85+00.000	-4.800%	Full Super	Linear
87+30.000	-4.800%	Full Super	Linear
88+00.000	-2.000%	Normal Crown	Linear
98+55.190	-2.000%	Normal Crown	Linear

Superelevation: NB

Station	Cross Slope	Point Type	Transition Type
50+00.000	-2.000%	Normal Crown	
58+15.000	-2.000%	Normal Crown	Linear
59+20.000	-6.000%	Full Super	Linear

d. Close the **Bentley Civil Report Browser**.

Exercise 5: Modifying Superelevation

In this exercise, you learn various methods for editing superelevation information.

Skills Taught

- Modify Superelevation Sections
- Modify Superelevation Graphically
- Modify Superelevation via Superelevation Model (Superelevation Diagram)
- Modify Superelevation via the Superelevation Table Editor

Modifying Superelevation Overview

Like many tools in OpenRoads Designer, the Superelevation tools are “rule based”. When superelevation sections and lanes are created, rules and relationships are established that associate the superelevation sections and lanes to the horizontal geometry. If the horizontal geometry were to change, the superelevation sections and lanes would change and follow the new geometry.

Once the superelevation lanes are drawn and calculated, they can be easily modified for project specific cases. In some cases, the transitions are modified automatically, when the horizontal geometry changes. Any transition that has rules (i.e. not imported) will automatically update any curve set where the horizontal geometry has changed. If the user changes the design speed for a curve set, it automatically recalculates any ruled transitions.

There are many ways to modify superelevation data. Options include:

- Modifying Superelevation Sections (for example, to adjust the stations limits, e_{max} or L selection).
- Modifying the Superelevation Lanes Graphically - Editing the station/cross slope via dynamic text or moving the graphic handlers.
- Using the Managed Superelevation Model (Superelevation Diagram) - Changing station and cross slope in the superelevation control line diagram.
- Superelevation Table Editor - Changing station, cross slope or other data in the table editor.

The various methods of modification can be used interchangeably at any time in the duration of the project, including after assigning to a corridor.

Tip: Since superelevation depends on the horizontal geometry reference file, you should never detach the horizontal geometry file. Doing so will break any rules and relationship that exist between the horizontal geometry and the superelevation data.

Review and Edit the Superelevation Section



1. Open the **Super-SR97.dgn** [*Metric - Super-SR97.dgn*].
2. Review the superelevation section properties.
 - a. Hover your cursor over the superelevation section shape until the context sensitive menu appears.



- b. **Select** the superelevation properties tool.
- c. **Review** the superelevation properties.

Feature Definition	Superelevation
Feature Name	SR97-1
Name	
Name	SR97-1
Horizontal Name	Route97-Extension
Standards File	c:\bentley training\using a
Design Speed	70
Pivot Method	Divided Inside
e Selection	6%
L Selection	Speed Table
Start Station	
Start Station	538+00.00
End Station	
End Station	816+11.92

Note that the superelevation section stores the limits and name of the superelevation section and also design criteria that was used to calculate the superelevation transitions. This is important because if you want to change any of the design criteria (name, station limits, xml file, design speed, pivot method, e selection, L selection) all you need to do is edit those parameters in the properties dialog and the calculations will update automatically.

3. Recalculate the superelevation transitions for a design speed of **55 mph [90 kph]**.
 - a. In the superelevation section properties, change the design speed to **55 [90]**

Feature Definition	Superelevation
Feature Name	SR97-1


Name	SR97-1
Horizontal Name	Route97-Extension
Standards File	c:\bentley training\using a
Design Speed	55
Pivot Method	Divided Inside
e Selection	6%
L Selection	Speed Table

Start Station	538+00.00
End Station	816+11.92

The software will re-calculate the superelevation transitions and update the color filled lanes.

Superelevation Diagram and Superelevation Managed Model

Once the superelevation calculations are assigned to the lanes a superelevation control line diagram is also created. The superelevation control line diagram can be viewed and edited by opening a superelevation managed model view (similar to the profile model and cross section model). The superelevation diagram is directly related to the superelevation lanes. Each superelevation control line represents a superelevation lane and its associated stations and cross slopes. Critical superelevation points are also created for normal crown, flat, reverse crown and full super locations. This allows for critical points to be constrained as needed when changes are made.



Changes made to the superelevation diagram will also carry over to the superelevation lanes. The superelevation diagram also supports annotation and can be clipped into sheets.

Be aware that deleting any control line in the superelevation diagram will remove the superelevation lanes.

Review and Edit the Superelevation Diagram

In this section, you will learn how to create the superelevation model view and edit the superelevation control lines.


1. Select the superelevation section.

a. Hover your cursor over the superelevation section shape until the context sensitive menu appears.




b. Select the **Open SuperElevation Model** tool.

c. When prompted to *Select or Open View*, open **View 8** by selecting the view 8 button from the bottom of the screen and then Left click in **View 8** to display the superelevation diagram.



Once the superelevation model view is open you will notice the superelevation control lines displayed in the view window. The control lines represent the superelevation transitions for the left and right lanes of the corridor. Each control line is created from the superelevation lane information and is “ruled” to each superelevation lane. Thus, changing the superelevation control lines will adjust the superelevation lane stations and slopes. Each control line can be graphically edited or reviewed by simply selecting it and editing the station and slope values.


2. Display the control lines for just the westbound left lane.
 - a. Right click and hold down the right mouse button in the superelevation view until the pop up menu appears.
 - b. Select **Select Lanes to Display**




- c. In the *Superelevation Lane Display* dialog, select the **SR97-1-CL_L-EOP_L** lane, the other lanes will un-highlight
- d. Left click **Apply**. The superelevation model will now display the control lines for only the westbound left lane.
- e. Close the *SuperElevation Lane Display* dialog.

3. Change the full superelevation slope to be **4%** [3.5%] at **571+25** [17+410.030] and **577+40** [17+600.030].

a. In the superelevation model view, zoom in near the first superelevation transition between **568+50** [17+325] and **580+00** [17+686].




b. Select the **SR97-1-CL_L - EOP_L** control line. Notice graphical manipulators and dynamic text appear indicating the stations and slope transitions. The stations and slopes can be edited by simply selecting the values and entering new values.



c. Left click the **3.80%** [4.00%] slope at **571+25** [17+410.030] and enter **4.0** [3.5] in the key-in field.

The superelevation diagram will update.


In the superelevation model, the control line critical points are colored either **green, yellow** or **red**. These 3 colors represent the control line point constraints. Similar to the component points of templates, green indicates an unconstrained point, yellow is a partially constrained point and red is a fully constrained point.



Control line constraints allow you to set slope and distance constraints to control line points within the same curve. This can be helpful when modifying control lines to ensure that information such as exact slopes, distances or slope transitions are maintained. To review and change constraints you must use the [Superelevation Table Editor](#), which we will discuss in the next section.

Review Superelevation Data Using the Table Editor

The superelevation table editor is an excellent way to view and edit superelevation data for each superelevation section. The table editor is customizable; columns can be sorted, hidden, rearranged, etc. Individual cells within the editor, or groups of cells can be changed, and graphic lanes are dynamically updated to keep the table editor and graphic lanes in sync. Any changes made in the editor are automatically synced with the graphic lanes and vice versa. Note the diagram within the table editor cannot be dynamically selected or changed.



Review and Modify Constraints

In this section, you will learn how to review and modify constraints using the superelevation table editor.


1. Open the Superelevation Editor.



a. Select **Corridors > Superelevation > Superelevation Editor**

b. *Locate Superelevation Section:* Select the superelevation section

The superelevation editor window will appear.




Note if you scroll to the right side of the editor, many of the fields are populated. Also note that some of the station/slope fields are grayed out. This indicates they are constrained. The type of constraint can be seen in the **Distance Constraint Type** and **Slope Constraint Type** columns.

The constraints are not based on beginning and end of a transition but from high to low side at a particular transition. Therefore, if you change the cross slope at the beginning of full super, it does not automatically change at the end. You will have to manually change it. However, if you change the high side of full super from -5.5% to 6.0%, the low side is automatically changed.

Viewing constraints

When working with constraints, it is useful to view the superelevation diagram at the top of the editor and also the table, the superelevation diagram can be toggled on/off as needed. Use the **Toggle Superelevation Diagram** button to turn off the superelevation diagram at the top of the editor.



The diagram is not interactive (i.e., you cannot click within it and edit it). Color coding indicates degree of constraint:

- Red – Fully Constrained
- Yellow – Partially Constrained
- Green – Unconstrained or No Constraints

As changes are made in the table, the diagram updates to reflect the modifications. A tool bar in the lower left corner of the diagram contains view controls and exaggeration buttons.

2. Review Slope Constraints and Modify Slopes.



a. Left-click the **Toggle Superelevation Diagram Button**, the superelevation diagram will undisplay.

Notice in the editor the **Distance Constraint Type** and **Slope Constraint Type** columns. These columns are used to define the type of constraints that can be defined. Also, notice the slope constraint at **577+40.00 [17+600.030]** has a **Cross Slope** constraint defined and the cross slope value is gray. Recall, any value shown in gray indicates it is constrained.

Superelevation	Name	Station	Curve Set	Cross Slope	Transition ...	Pivot Edge	Non L...	Point Type	Ignore	Distance Constraint ...	Distance Transi...	Distance Transio...	Offset	Slope Constraint Type	Superelevation Constrai
CL_L - EOP_L	CL_L - EOP_L - 537+99	538+00.0000	0	-2.00%	Linear	Right Edge		Normal Crown	False	None			0.000	None	
CL_L - EOP_L	CL_L - EOP_L - 568+86	568-85.0000	0	-2.00%	Linear	Right Edge		Normal Crown	False	None			0.000	None	
CL_L - EOP_L	CL_L - EOP_L - 569+61	569+63.3333	0	0.00%	Linear	Right Edge		Super Runoff	False	Vector Slope	CL_L - EOP_L - 56...	CL_L - EOP_L - 571+19	0.000	None	
CL_L - EOP_L	CL_L - EOP_L - 570+40	570+41.6667	0	2.00%	Linear	Right Edge		Reverse Crown	False	Vector Slope	CL_L - EOP_L - 56...	CL_L - EOP_L - 571+19	0.000	None	
CL_L - EOP_L	CL_L - EOP_L - 571+19	571+20.0000	0	4.00%	Linear	Right Edge		Full Super	False	None			0.000	None	
CL_L - EOP_L	CL_L - EOP_L - 577+46	577-45.0000	0	4.00%	Linear	Right Edge		Full Super	False	None			0.000	Cross Slope	
CL_L - EOP_L	CL_L - EOP_L - 578+24	578-23.3333	0	2.00%	Linear	Right Edge		Reverse Crown	False	Vector Slope	CL_L - EOP_L - 57...	CL_L - EOP_L - 577+46	0.000	None	
CL_L - EOP_L	CL_L - EOP_L - 579+00	579+01.6667	0	0.00%	Linear	Right Edge		Super Runoff	False	Vector Slope	CL_L - EOP_L - 57...	CL_L - EOP_L - 577+46	0.000	None	
CL_L - EOP_L	CL_L - EOP_L - 579+78	579+80.0000	0	-2.00%	Linear	Right Edge		Normal Crown	False	None			0.000	None	

3. Change the 4.00% cross slope at **571+25.00 [17+410.030]** to **3.5% [3.0%]**.

a. Select the **4.00%** cross slope that occurs at **571+25.00 [17+410.030]** (this is where full superelevation begins).

Superelevation	Name	Station	Curve Set	Cross Slope	Transition ...	Pivot Edge	Non L...	Point Type	Ignore	Distance Constraint Type	Distance Transition
CL_L - EOP_L	CL_L - EOP_L - 537+99	538+00.00	0	-2.00%	Linear	Right Edge		Normal Crown	False	None	
CL_L - EOP_L	CL_L - EOP_L - 568+89	568+90.00	0	-2.00%	Linear	Right Edge		Normal Crown	False	None	
CL_L - EOP_L	CL_L - EOP_L - 569+68	569+68.33	0	0.00%	Linear	Right Edge		Super Runoff	False	Vector Slope	CL_L - EOP_L - 568+89
CL_L - EOP_L	CL_L - EOP_L - 570+47	570+46.67	0	2.00%	Linear	Right Edge		Reverse Crown	False	Vector Slope	CL_L - EOP_L - 569+68
CL_L - EOP_L	CL_L - EOP_L - 571+25	571+25.00	0	4.00%	Linear	Right Edge		Full Super	False	None	
CL_L - EOP_L	CL_L - EOP_L - 577+39	577+40.00	0	4.00%	Linear	Right Edge		Full Super	False	None	
CL_L - EOP_L	CL_L - EOP_L - 578+18	578+18.33	0	2.00%	Linear	Right Edge		Reverse Crown	False	Vector Slope	CL_L - EOP_L - 578+96
CL_L - EOP_L	CL_L - EOP_L - 578+96	578+96.67	0	0.00%	Linear	Right Edge		Super Runoff	False	Vector Slope	CL_L - EOP_L - 579+75
CL_L - EOP_L	CL_L - EOP_L - 579+75	579+75.00	0	-2.00%	Linear	Right Edge		Normal Crown	False	None	
CL_L - EOP_L	CL_L - EOP_L - 621+81	621+83.33	0	-2.00%	Linear	Right Edge		Normal Crown	False	Vector Slope	EOP_RM - CL_L - 620+
CL_L - EOP_L	CL_L - EOP_L - 622+60	622+60.00	0	-4.00%	Linear	Right Edge		Full Super	False	Distance Offset	EOP_RM - CL_L - 622+
CL_L - EOP_L	CL_L - EOP_L - 625+26	625+25.00	0	-4.00%	Linear	Right Edge		Full Super	False	Distance Offset	EOP_RM - CL_L - 625+
CL_L - EOP_L	CL_L - EOP_L - 626+04	626+03.33	0	-2.00%	Linear	Right Edge		Normal Crown	False	Vector Slope	EOP_RM - CL_L - 627+
CL_L - EOP_L	CL_L - EOP_L - 719+19	719+20.61	0	-2.00%	Linear	Right Edge		Normal Crown	False	Vector Slope	EOP_RM - CL_L - 717+
CL_L - EOP_L	CL_L - EOP_L - 720+24	720+25.00	0	-4.60%	Linear	Right Edge		Full Super	False	Distance Offset	EOP_RM - CL_L - 720+

b. In the input field, key-in **3.5 [3.0%]** and press **<Enter>**

	Superelevation	Name	Station	Curve Set	Cross Slope	Transition ...	Pivot Edge	Non L...	Point Type	Ignore	Distance Constraint Type	Distance Transition 1
	CL_L - EOP_L	CL_L - EOP_L - 537+99	538+00.00	0	-2.00%	Linear	Right Edge		Normal Crown	False	None	
	CL_L - EOP_L	CL_L - EOP_L - 568+89	568+90.00	0	-2.00%	Linear	Right Edge		Normal Crown	False	None	
	CL_L - EOP_L	CL_L - EOP_L - 569+75	569+75.45	0	0.00%	Linear	Right Edge		Super Runoff	False	Vector Slope	CL_L - EOP_L - 568+89
	CL_L - EOP_L	CL_L - EOP_L - 570+60	570+60.91	0	2.00%	Linear	Right Edge		Reverse Crown	False	Vector Slope	CL_L - EOP_L - 569+75
▶	CL_L - EOP_L	CL_L - EOP_L - 571+25	571+25.00	0	3.50%	Linear	Right Edge		Full Super	False	None	
	CL_L - EOP_L	CL_L - EOP_L - 577+39	577+40.00	0	3.50%	Linear	Right Edge		Full Super	False	None	
	CL_L - EOP_L	CL_L - EOP_L - 578+05	578+04.09	0	2.00%	Linear	Right Edge		Reverse Crown	False	Vector Slope	CL_L - EOP_L - 578+90
	CL_L - EOP_L	CL_L - EOP_L - 578+90	578+89.55	0	0.00%	Linear	Right Edge		Super Runoff	False	Vector Slope	CL_L - EOP_L - 579+75
	CL_L - EOP_L	CL_L - EOP_L - 579+75	579+75.00	0	-2.00%	Linear	Right Edge		Normal Crown	False	None	

Notice that when you changed the cross slope at **571+25 [17+410.030]**, the cross slope at **577+40 [17+600.030]** also changed.

Why? This happens because the point at **577+40 [17+600.030]** is cross slope constrained to the point at **571+25 [17+410.030]**.


The *Slope Transition 1* column determines which point you constrain the cross slope to.

Station	Curve Set	Cross Slope	Transition Type	Pivot Edge	Non Linear Curv...	Point Type	Ignore	Distance Constr...	Distance Transi...	Distance Transi...	Offset	Slope Constraint...	Superelevation ...	Slope Transition 1
... 538+00.00	0	-2.00%	Linear	Right Edge		Normal Crown	False	None			0.000	None		
... 568+91.47	0	-2.00%	Linear	Right Edge		Normal Crown	False	None			0.000	None		
... 569+76.39	0	0.00%	Linear	Right Edge		Super Runoff	False	Vector Slope	CL_L - EOP_L - 5...	CL_L - EOP_L - 5...	0.000	None		
... 570+61.31	0	2.00%	Linear	Right Edge		Reverse Crown	False	Vector Slope	CL_L - EOP_L - 5...	CL_L - EOP_L - 5...	0.000	None		
... 571+25.00	0	3.50%	Linear	Right Edge		Full Super	False	None			0.000	None		
... 577+40.00	0	3.50%	Linear	Right Edge		Full Super	False	None			0.000	Cross Slope		CL_L - EOP_L - 571+25
... 578+03.69	0	2.00%	Linear	Right Edge		Reverse Crown	False	Vector Slope	CL_L - EOP_L - 5...	CL_L - EOP_L - 5...	0.000	None		

c. Close the *Superelevation Editor*.

4. Review the Superelevation Lanes and Constraints in plan view.
 - a. Select any superelevation lane (The station/cross slope and graphic handlers will appear).

Notice that some of the values appear gray. **Why?** Again, this relates back to the superelevation constraints. Wherever constraints exist the values will appear gray and you will not be able to modify the values in plan view. They can only be modified via the superelevation table editor.




- b. Left click anywhere in *View 1* to de-select the lanes.


Adding a Transition to Existing Lanes

There may be project specific cases where you need to split an existing super lane into two by adding a new transition station and associated cross slope. Examples include matching into cross roads, gore areas, etc. This type of editing is easily done with the **Insert Superelevation Station / Cross-Slope** tool. In this section we will add a cross slope transition to the westbound lanes.

1. Edit beginning cross slopes for the westbound lanes at **538+00 [16+400]**.
 - a. Zoom in near the beginning of the westbound superelevation lanes at **538+00 [16+400]**.



- b. Select the westbound left lane.
- c. Left click the -2.00% cross slope and key-in **-1.60%**
- d. Left click anywhere in the view to de-select the lane.
- e. Select the westbound right lane.
- f. Left click the 2.00% cross slope and key-in **1.60%**
- g. Left click anywhere in the view to de-select the lane.



2. Repeat the steps above for the Eastbound Lanes, Eastbound Left Lane slope will be 1.60% and Eastbound Right slope will be -1.60%

3. Add a cross slope transition at **540+00 [16+460]** for the westbound left lane.

a. Select **Corridors > Superelevation > Insert Station Cross Slope**

b. Following the heads up prompts (after each prompt, **Left click** to accept values and move to next prompt):


- *Locate Superelevation:* **Select the westbound left lane**
- *Distance Constraint:* **None**
- *Slope Constraint:* **None**
- *Pivot About:* **Right Edge**
- *Transition Type:* **Linear**
- *Station:* **540+00 [16+460]**, press **<Enter>** to lock the station value.
- *Cross Slope:* **-2.00%**
- *Point Type:* **Normal Crown**

c. Reset to complete.


4. Add cross slope transition at **540+00 [16+460]** for the westbound right lane.

a. Following the heads up prompts (after each prompt, **Left click** to accept values and move to next prompt):


- *Locate Superelevation:* **Select the westbound right lane**
- *Distance Constraint:* **None**
- *Slope Constraint:* **None**
- *Pivot About:* **Right Edge**
- *Transition Type:* **Linear**
- *Station:* **540+00 [16+460]**, press **<Enter>** to lock the station value.
- *Cross Slope:* **2.00%**
- *Point Type:* **Normal Crown**



5. Add cross slope transition at **540+00 [16+460]** for the Eastbound Lanes.
 - a. Repeat the steps above for the Eastbound Left and Right Lanes. The Eastbound Left Lane Slope (inside lane) will be **2.00%** and the Eastbound Right Lane Slope (outside lane) will be **-2.00%**
6. Review the cross slopes you created at **538+00 [16+400]** and **540+00 [16+460]**.
 - a. **Select the westbound left lane** and note the **-1.60%** and **-2.00%** cross slopes at **538+00 [16+400]** and **540+00 [16+460]**.



- b. Left click anywhere in **View 1** to de-select the westbound left lane.
- c. Select the **westbound right lane** and note the **1.60%** and **2.00%** cross slopes at **538+00 [16+400]** and **540+00 [16+460]**.



- d. Left click anywhere in **View 1** to de-select the westbound right lane.

Exercise 6: Auxiliary Lanes - Adding Lanes


So far, we have focused on the through lanes, but most projects will have auxiliary lanes that are a short segment within the project. Examples include turn lanes, truck climbing lanes, entrance and exit lanes, or expansion of the roadway from two lanes to four lanes, etc. These types of lanes can be added at any time during the project. In this exercise you will learn how to add auxiliary lanes to the westbound and eastbound lanes.

Skills Taught

- Adding Auxiliary Lanes

Primary vs. Auxiliary Lanes

The main consideration for these lanes is how the cross slope is defined. If the cross slope transitions are ruled, i.e., based on calculations from superelevation XML file, then it's a Primary lane. If the cross slope is user-defined or matching the adjacent lane, then it is an Auxiliary lane. The *Create Superelevation Lanes* tool is used to define if a lane is primary or auxiliary.



The screenshot shows a dialog box titled "Create S..." with the following fields and values:

Name	EB Auxiliary Lane
Type	Auxiliary
Application Type	None
Side Of Centerline	Right
Inside Edge Offset	0.000
Width	12.000
Lock To Start	<input type="checkbox"/>
<input type="checkbox"/> Start Station	500+00.00
Lock To End	<input type="checkbox"/>
<input type="checkbox"/> End Station	500+00.00
Normal Cross Slope	-2.00%

The slope of an auxiliary lane is determined by the *Application Type* which can be set to **Follow Adjacent** or **Constant**. When **Follow Adjacent** is used the cross slope will be determined from the adjacent superelevation lane. When **Constant** is used a constant cross slope is applied to the auxiliary lane utilizing the value in the *Normal Cross Slope* field.

An auxiliary lane must be all inclusive within a single superelevation section. Therefore, you may have to move section limits to accomplish this, after they are automatically created.

If the lane is tapered (such as a turn lane), the lane width can be any width. The actual drawing of the taper at the correct widths is handled within the corridor, only the slopes are used from the superelevation lane.


Add Auxiliary Lanes

In this section, you will add an auxiliary lane at the end of the project for the eastbound lanes. Recall, there are currently 2 lanes for westbound and eastbound. We will add a third lane to eastbound lanes.



1. Add a third lane to the eastbound lanes from **763+50 [23+270]** to **816+11.92 [24+875.362]**.
 - a. Select **Corridors > Superelevation > Create > Create Superelevation Lanes**
 - b. Following the heads up prompts (after each prompt, **Left click** to accept values and move to next prompt):

- *Locate First Superelevation Section: Select the SR97-1 superelevation section*
- *Locate Next Superelevation Section-Reset To Complete: Right click or Reset*
- *Enter Lane Name: EB Auxiliary Lane*
- *Type: Auxiliary*
- *Application Type: Constant*
- *Side of Centerline: Right*
- *Inside Edge Offset: 49 [13.60]*
- *Width: 12 [3.6]*
- *Start Station: 763+50 [23+270]*
- *End Station: Press ALT to Lock to End Station*
- *Normal Cross Slope: -2.5*



2. Verify the station and cross slopes.
 - a. Select the auxiliary lane.
 - b. Review the stations and cross slopes.

The stations should match the values entered previously and the cross slopes should be **-2.5%**.

MANIPULATION OF AUXILIARY LANES

The ability to manipulate an auxiliary lane is related to the *Application Type* (**Follow Adjacent** or **Constant**).

If **Follow Adjacent** is used, the edit handlers are tied to the adjacent lane. If you move the station graphically, both handlers move. If you change the station or cross slope of the main lane, the station of the adjacent lane is also changed. If you view the auxiliary lane in the table editor, the station and cross slopes are ghosted as read-only. Again, if you manipulate the main lane, the auxiliary lane automatically changes to reflect the Follow Adjacent status. A single station / cross slope can be inserted in the auxiliary lane, so this is the only manipulation made independent of the adjacent lane.

If the **Constant** option is used, the lane can be easily manipulated by the methods previously discussed:

- Changing superelevation transition station or cross slope dynamically.
- Changing station, cross slope or other data in the table editor.

It is also easy to change the constant option to reflect a transition lane. For example, you can set the constant slope to -2% during creation, then modify the cross-slope at one end to -4%. You can also use the Insert Superelevation Station / Cross Slope tool for further modification.

Exercise 7: Assigning Superelevation to Corridors

So far we have learned how to create superelevation sections, lanes and calculate superelevation transitions. Once the superelevation calculations are complete you need to assign the superelevation lanes to a corridor in order for the template cross slopes to follow the superelevation cross slopes. In this exercise you will learn how to assign superelevation lanes to a corridor and how to review the cross sections.

Skills Taught

- Assign Superelevation To Corridor
- Review Superelevation Cross Sections
- Review Superelevation Flags and Point Controls

Assign Superelevation to Corridor

In this section, we will assign the superelevation lanes to the SR97 corridor and review the cross sections.

1. Assign superelevation lanes to the SR97 corridor.



a. Open the **Corridor-SR97.dgn** [*Metric - Corridor-SR97.dgn*]. This file already has the terrain, geometry and superelevation files attached as reference files. The geometry and superelevation files must be attached to a corridor in order to assign superelevation to a corridor.



b. Select **Corridors > Superelevation > Calculate > Assign To Corridor**

c. Following the heads up prompts (after each prompt, **Left click** to accept values and move to next prompt):

- *Locate First Superelevation Section: Select the superelevation section*
- *Locate Next Superelevation Section-Reset To Complete: Right click or Reset*
- *Locate Corridor: Select the corridor*

The Associate Superelevation dialog will appear.

	Superelevation Lane	Superelevation Point	Pivot Point	Start Station	Stop Station	Priority
▶	CL_L - EOP_L	EOP_L	CL_L	500+00.0000	816+11.9186	1
	EOP_RM - CL_L	CL_L	EOP_RM	500+00.0000	816+11.9186	1
	EOP_LM - CL_R	CL_R	EOP_LM	500+00.0000	816+11.9186	1
	CL_R - EOP_R	LL_R	CL_R	500+00.0000	816+11.9186	1
*	EB Auxiliary Lane	EOP_R	LL_R	500+00.0000	816+11.9186	1

TIP: Each superelevation lane is associated to template points that have been flagged to be used with superelevation. Those template points will be used to define how the pavement will be superelevated. The *Superelevation Lane* represents the name of each superelevation lane, the *Pivot Point* defines the point of rotation and the *Superelevation Point* is the template point that will be superelevated. Superelevation point controls are then created and assigned to the corridor.

Since we added an auxiliary lane and we have multiple template drops in the corridor we need to adjust some stations and add an additional point control to the dialog so that the superelevation point controls get created correctly.

2. Adjust the Start Station for the **CL_R-EOP_R** Superelevation Lane (this is eastbound right lane).
 - a. Key-in **763+50 [23+270]**
3. Adjust the Start Station for the **EB Auxiliary Lane** Superelevation Lane (this is the auxiliary lane).
 - a. Key-in **763+50 [23+270]**

Associate Superelevation


	Superelevation Lane	Superelevation Point	Pivot Point	Start Station	Stop Station	Priority
	CL_L - EOP_L	EOP_L	CL_L	500+00.0000	816+11.9186	1
	EOP_RM - CL_L	CL_L	EOP_RM	500+00.0000	816+11.9186	1
	EOP_LM - CL_R	CL_R	EOP_LM	500+00.0000	816+11.9186	1
	CL_R - EOP_R	LL_R	CL_R	763+50.0000	816+11.9186	1
	EB Auxiliary Lane	EOP_R	LL_R	763+50.0000	816+11.9186	1
▶	CL_R - EOP_R	EOP_R	CL_R	538+00.0000	763+50.0000	1
*						

OK Cancel


4. Add an additional superelevation point control for **CL_R-EOP_R** from **538+00 [16+400]** to **763+50 [23+270]**.
 - a. From the *Associate Superelevation* dialog, Select the bottom row (under EB Auxiliary Lane).
 - b. Use the drop down arrow in the *Superelevation Lane* column and select **CL_R-EOP_R**
 - c. Select the drop down arrow in the *Superelevation Point* column and select **EOP_R**
 - d. Section the drop down arrow in the *Pivot Point* column and select **CL_R**
 - e. Set the *Start Station* value to **538+00 [16+400]**
 - f. Set the *Stop Station* value to **763+50 [23+270]**
 - g. Set the *Priority* to **1**
 - h. Click **OK** to complete.

There are several ways to view the updated corridor once superelevation has been assigned. These include reviewing the 3D model in an isometric view, creating a report, or dynamic cross sections.


5. Review the superelevation information on the dynamic cross sections.
 - a. In *View 8*, the dynamic cross sections are already set up.
 - b. Navigate through the cross sections and notice how the pavement is superelevated and also notice there are numerous point controls assigned to the template points that are superelevated. A magenta square box indicates a point control.



6. Place Temporary Dimension Lines and review the cross slopes.
 - a. In *View 8*, Right click and hold down the right mouse button until the pop up menu appears.
 - b. Select **Place Horizontal Temporary Dimension**
 - c. *Identify the Start Point:* Select the **CL_R** (eastbound crown point).
 - d. *Identify the End Point:* Select the **EOP_R** (eastbound edge of pavement point).
 - e. *Dimension Height:* Left click anywhere above the cross section to finish placing the dimension line.



7. Using the previous steps create temporary dimension lines for the remaining pavement points for eastbound and westbound.



► 8. Navigate through the cross sections and review the superelevation cross slope values.



9. Review the superelevation point controls in the corridor.

a. Select **Corridors > Edit > Corridor Objects**

a. Locate and select the corridor. The *Corridor Objects* dialog will appear.

b. Select **Point Controls** and review the superelevation point controls that were created.

The screenshot shows the 'Corridor Objects - Route97-Extension' dialog box. On the left is a tree view with 'Point Control' selected. The main area contains a table of point controls:

Enabled	Control Descripti...	Mode	Control Type	Use as Second...	Priority	Start Station	End Station
True		Vertical	Superelevation		1	538+00.0000	816+11.9186
True		Vertical	Superelevation		1	538+00.0000	816+11.9186
True		Vertical	Superelevation		1	538+00.0000	816+11.9186
True		Vertical	Superelevation		1	763+50.0000	816+11.9186
True		Vertical	Superelevation		1	763+50.0000	816+11.9186
True		Vertical	Superelevation		1	538+00.0000	763+50.0000

Below the table is a 'Station Range' section with the following values:

Station Range	Value
Start Station	538+00.0000
End Station	816+11.9186

The right side of the dialog shows a detailed view of the selected 'PointControl' with the following settings:

Property	Value
Enabled	<input checked="" type="checkbox"/>
Control Description	
Mode	Vertical
Control Type	Superelevation
Point	EOP_L
Superelevation	SR97-1: CL_L - EOP_L
Reference Point	CL_L
Priority	1

Always review the point controls. If the cross sections are not superelevating correctly it's most likely because there is an error in point control creation or the superelevation flags are set incorrectly in the template.

c. Close the *Corridor Objects* dialog.

Exercise 8: Automated Superelevation Method

In this exercise, you will learn how to calculate and assign superelevation to a corridor using the automated superelevation method.

Skills Taught

- Calculate and Assign Superelevation using the Automated Superelevation Method
- Calculate Superelevation for Multiple Design Speeds
- Assign Superelevation to Corridor
- Review Superelevation Cross Sections
- Review Superelevation Report

Automated Superelevation Method

Up to this point, we have learned how to create superelevation by creating superelevation sections, creating lanes and then calculating superelevation transitions. There is also a way to automate the superelevation process using the automated superelevation method. The automated superelevation method eliminates the individual steps for creating the sections, lanes, calculating superelevation and corridor assignment.

The automated superelevation process automatically creates the superelevation section(s), builds the lanes, calculates the superelevation and assigns it to the corridor using only one tool. In order for this to work:

- You must create your Superelevation in the same file as the corridor.
- When creating the Superelevation section(s), pick the **Corridor** instead of the Alignment

Using the 'default settings' in the XML preference file, the process will:


- Create the super section(s)
- Build the lanes from the corridor configuration
- Calculate the superelevation
- Assigns it to the corridor and create point controls

Note: If you are not in the same file as the corridor, superelevation point controls will not be created. You will just get the superelevation sections, lanes and transitions.

Create Superelevation for Ramp C Using Automated Method

In this section, we are going to create the superelevation transitions for Ramp C using the automated superelevation method. We are also going to create multiple superelevation sections since the ramp has multiple design speeds.

1. Open **Corridor-RampC.dgn** [[Metric - Corridor-RampC.dgn](#)]
2. Adjust Superelevation Rule File.
 - a. Select **Corridors > Superelevation > Calculate > Edit Superelevation Rule File**
 - b. Open **c:\Bentley Training\Using and Defining Superelevation\AASHTO_2011_Imperial.xml** [[AASHTO_2011_Metric.xml](#)]
 - c. Select the **General** category from the *Create/Edit Superelevation XML* dialog box.
 - d. In the **Calculate Superelevation Default Setting (optional)** portion of the dialog, set the design parameters as follows:
 - *e Max Method*: **6%**
 - *Runoff Length Method*: **AASHTO Relative Gradient**
 - *Pivot Method*: **Right Edge**
 - *Design Speed*: **45 MPH [70 kph]**



- e. Go to **File > Save** to save the Superelevation Rule File.
- f. Close the *Create/Edit Superelevation XML* dialog.
- g. Select **Yes** when prompted to save before closing.

3. Create the superelevations data for Ramp C.



- a. Select **Corridors > Superelevation > Create > Create Superelevation Sections**
- b. Following the heads up prompts,
 - *Name:* **Ramp C**
 - *Locate Corridor or Select Alignment:* Select **Ramp C** Corridor
 - *Select the XML Rules File - <ALT> Down To Browse XML Rule Files:* Press **<ALT><DOWN>** and Select **C:\Bentley Training\Using and Defining Superelevation\AASHTO_2011_imperial.xml [AASHTO_2011_metric.xml]**
 - *Enter Minimum Tangent Length:* **0** (set this to 0 so that multiple sections get created. Ramps typically are designed with multiple design speeds thus multiple sections will be required for this example).

The superelevation lanes will be created based on the template that is assigned to the corridor. The superelevation transitions will be calculated and automatically assigned to the lanes as well as the corridor.

- 4. **Review** the cross sections to make sure they are superelevating correctly.
- 5. Change the design speed for the second curve.



- a. Using the superelevation section properties. Select the second superelevation section.
- b. Change the design speed for the second curve to **35 mph [50 kph]**. The superelevation transitions will re-calculate and update based on the new design speed.

Feature Definition	Superelevation
Feature Name	Ramp C-2
Name	Ramp C-2
Horizontal Name	RampC
Standards File	C:\ProgramData\Bentley\
Design Speed	35
Pivot Method	Right Edge
e Selection	6%
L Selection	AASHTO Relative Gradien
Start Station	23+37.8124
End Station	30+79.6264

6. Review the superelevation transitions using the Superelevation Report.

a. Select **Corridors > Superelevation > Superelevation Report**

- **Locate First Superelevation Section:** Select the first superelevation section based on the **45 mph [70 kph]**.
- **Locate Next Superelevation - Reset To Complete:** Select the second superelevation section based on the **35 mph [50 kph]**.

Superelevation Data Report
 Report Created: Thursday, February 6, 2020
 Time: 1:20:39 PM

Note: All units in this report are in feet unless specified otherwise.

Section 1: Ramp C-1
 File Name: Ramp C-1
 Input Grid Factor:
 Standards Filename: C:\Bentley Training\Using and Defining Superelevation\AASHTO_2011_imperial.xml
Design Speed: 45
 Pivot Method: Right Edge
 E Selection: 6%
 L Selection: AASHTO

Station	Cross Slope	Point Type	Transition Type
10+00.000	2.000%	Normal Crown	
15+60.000	2.000%	Normal Crown	Linear
16+50.000	5.000%	Full Super	Linear
20+40.000	5.000%	Full Super	Linear
21+30.000	2.000%	Normal Crown	Linear
23+37.812	2.000%	Normal Crown	Linear

Section 2: Ramp C-2
 File Name: Ramp C-2
 Input Grid Factor:
 Standards Filename: C:\Bentley Training\Using and Defining Superelevation\AASHTO_2018_imperial.xml
Design Speed: 35
 Pivot Method: Right Edge
 E Selection: 6%
 L Selection: AASHTO

Station	Cross Slope	Point Type	Transition Type
23+37.812	2.000%	Normal Crown	
24+62.619	2.000%	Normal Crown	Linear

Notice the report displays the two different design speeds used to perform the superelevation calculations for each section.

Skills Assessment

The questions below will test your retention of the skills covered in this course.

1. Superelevation is calculated using the Superelevation XML Preferences File?
 - a. True
 - b. False
2. If superelevation was created using the rules file, what happens to the superelevation calculations if the geometry changes?
 - a. If superelevation was created using the rules file then the calculations will update based on the geometry changes.
 - b. The superelevation will not update at all.
 - c. If the geometry changes you have to re-import your superelevation calculations.
3. Changing the design speed in the properties of the superelevation section will update the superelevations calculations?
 - a. True
 - b. False
4. Multiple superelevations are typically used for:
 - a. Projects that have multiple design speeds or for users that prefer to create/edit calculations per curve set.
 - b. Divided highway situations.
 - c. Ramp geometry that has reverse curves and spirals.
5. When importing superelevation from a .csv file the superlevation transitions will automatically update if the geometry is changed?
 - a. True
 - b. False

Skills Assessment - Answers

1. Superelevation is calculated using the Superelevation XML Preferences File?
 - a. **True**
 - b. False
2. If superelevation was created using the rules file, what happens to the superelevation calculations if the geometry changes?
 - a. **If superelevation was created using the rules file then the calculations will update based on the geometry changes.**
 - b. The superelevation will not update at all.
 - c. If the geometry changes you have to re-import your superelevation calculations.
3. Changing the design speed in the properties of the superelevation section will update the superelevations calculations?
 - a. **True**
 - b. False
4. Multiple superelevations are typically used for:
 - a. **Projects that have multiple design speeds or for users that prefer to create/edit calculations per curve set.**
 - b. Divided highway situations.
 - c. Ramp geometry that has reverse curves and spirals.
5. When importing superelevation from a .csv file the superlevation transitions will automatically update if the geometry is changed?
 - a. True
 - b. **False**

Summary

In this course you have learned many tools and techniques for creating, editing and reviewing superelevation.

You have learned how to:

- Review and Edit Superelevation XML Preferences File
- Create Superelevation Sections and Lanes
- Calculate Superelevation
- Create and Review Superelevation Reports
- Import Superelevation Data
- Modify Superelevation
- Assign Superelevation to Corridors and Review Cross Sections